




WHAT'S IN THE BOX

* Change the speaker before first use. For safety and peak performance, use genuine JBL batteries. Non-original batteries may pose safety and reliability risks.


** Power cord quantity and plug type vary by regions.




BLUETOOTH PAIRING



PLAY




LIGHTSHOW






Apply lightshow presets and more with the JBL ONE app.

APP*




Download and install the JBL ONE app to get more from the product.




* Зауважте, що зараз деякі сервіси можуть бути тимчасово недоступними на території України або можуть не підтримувати українську мову.

MICROPHONE/GUITAR



OPTICAL



* Specify "PCM" as the digital audio output method on the TV.

MULTI-SPEAKER CONNECTION



CHARGING




Due to local laws and regulations, the Powerbank function may be unavailable in certain regions. Please refer to local regulations. | 由于当地法律法规的限制，移动电源功能在某些地区可能无法使用。请参考当地相关规定。

HANDLE



BATTERY REPLACEMENT



Change the battery before first use.

